

## Concrete Repair Kit

Model #: Repair – (BA, CB, CN, DB, FO, LB, SD,  
SL, SM, SP, TR, TS, VA, WA)

**INSTALLER:** Leave these instructions with consumer.  
**CONSUMER:** Retain for future reference.



### SUPPLIES IN KIT

- Latex Gloves (2 pairs)
- Plastic Cups (3)
- Metal Strips (4)
- Round sponge
- Color Grout Mix (1 bottle)
- White Admix Liquid (1 bottle)
- Cement Sealer (1 bottle)
- Liquid Pigment (1 bottle, Antique/Reclaimed wood kits only)

This kit is used for minor concrete repairs on American Fyre Designs products. **Actual color-matching results may vary depending on application.**

1. **Ensure that the unit is OFF and completely cool, and that the gas supply to the unit is turned OFF.**
2. Wear gloves before beginning repair.
3. Clean the repair area with cold water and mild soap using the sponge. Be sure to rinse the area thoroughly to prevent any residual soap deposits.
4. Pour a small amount of color grout mix into a cup, estimating the amount needed for the repair.
5. Add a small amount of white Admix liquid into the cup. Stir with a metal strip. For larger repairs, use a thick, toothpaste-like consistency. For small repairs or fine cracks, use a slightly more runny consistency. Add more color grout mix or white Admix liquid to achieve desired thickness.
6. Let the mixture sit for approximately 15 minutes before application. Stir after to ensure thoroughly mixed before application.
7. Use the metal strip to apply mixture to the damaged area. Mold it to conform to the area's original shape. Repeat steps 4 and 5 if more mixture is needed.
8. Wait approximately 5 minutes. If necessary, gently pat the repaired area with a damp sponge or a soft cloth to smooth out the edges. Repeat process until desired surface is achieved.
9. Allow to dry for 3 hours. Clean repaired area with a damp sponge.
10. For **Antique/Reclaimed wood** models, add the liquid pigment to the repair area and allow to set for 10 minutes. Then wipe clean with a clean cloth.
11. Allow to dry for 30 minutes. Repeat step 10 and 11 until desired shade is obtained.
12. Apply the supplied cement sealer with brush or rag to seal the repair and preserve the finish. Let dry for 24 hours. For large repairs it is recommended to reseal the surrounding area or the entire unit.