


ROUND WIND GUARD

Model: 8208-WG




SPECIFICATIONS AND DIMENSIONS

This wind guard is for use with your American Fyre Designs firetable.

CAUTION: <u>DO NOT touch any part of this accessory during operation or when HOT! The glass panels and other surfaces get HOT and can cause burns if touched.</u>

Be sure the firetable and this accessory are completely cool when handling.



TOOLS REQUIRED

- Phillips screwdriver
- 2 assemblers recommended
- Soft cotton gloves for handling glass panels

Note: Use a soft non-abrasive surface for assembly to prevent any damage.







8208-02


4x



Bottom bracket

8208-03

4x



Glass panel


8208-01

4x



Remove all packing material and discard prior to use.






Assemble upside down (as shown) for ease of assembly.


Top bracket

2 Assemble all panels w/ remaining top brackets




DO NOT overtighten screws. Tighten until snug. Overtightening can break glass.

3 Install bottom brackets




DO NOT overtighten screws. Tighten until snug. Overtightening can break glass.



Gently secure all screws (on all brackets) $^{1}/_{4}$ " to $^{1}/_{2}$ " turn until panels are secure. DO NOT OVERTIGHTEN.

5 Install on firetable



Flip and position wind guard on firetable.

CARE AND CLEANING

- Clean the glass periodically to remove any buildups caused by the elements and combustion. It is recommended that the glass be cleaned 2-3 times during each heating season, depending on use and environment conditions.
- Clean using a non-abrasive glass cleaner and a clean lint-free cloth.
- · Never attempt to clean glass while hot.
- DO NOT touch glass while in operation or within 10 minutes following use.

