

# FIREMAGIC®

## GRILLING TRAY

Model # 3567

**IMPORTANT:** READ THESE INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION OR USE.

Congratulations on the purchase of the Fire Magic grilling tray! We are sure it will prove to be of great value to you when grilling for your family, friends, and guests with your Fire Magic grill. The grilling tray has been designed for easy and trouble-free grilling of vegetables, small pieces of fish, and chopped meats.


To use, simply place the tray on the pre-heated cooking grids when you are ready to grill your vegetables. Allow it to warm up. Place your food on the tray and grill as normal, stirring occasionally. When cooked, either serve the food directly from the tray or move the food to a suitable container for serving.

**Note:** The grilling tray is constructed of the highest quality materials. Due to the nature of these materials, slight warping of the grilling tray may occur during the warm-up period. This will not alter its performance.

**Note:** The grilling tray has a porcelain coating that is dish washer safe, but can be chipped or damaged by rough handling.

**CAUTION:** **BURN HAZARD. This accessory will be hot during use and will retain heat for some time after.** Always use protective oven gloves or a pot holder when handling the tray during, and immediately after use. Keep children away from the grill during use.

Robert H. Peterson Co. • 14724 East Proctor Avenue • City of Industry, CA 91746



REV 0 - A - 2205271500

L-C2-688

# FIREMAGIC®

## GRILLING TRAY

Model # 3567

**IMPORTANT:** READ THESE INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION OR USE.

Congratulations on the purchase of the Fire Magic grilling tray! We are sure it will prove to be of great value to you when grilling for your family, friends, and guests with your Fire Magic grill. The grilling tray has been designed for easy and trouble-free grilling of vegetables, small pieces of fish, and chopped meats.


To use, simply place the tray on the pre-heated cooking grids when you are ready to grill your vegetables. Allow it to warm up. Place your food on the tray and grill as normal, stirring occasionally. When cooked, either serve the food directly from the tray or move the food to a suitable container for serving.

**Note:** The grilling tray is constructed of the highest quality materials. Due to the nature of these materials, slight warping of the grilling tray may occur during the warm-up period. This will not alter its performance.

**Note:** The grilling tray has a porcelain coating that is dish washer safe, but can be chipped or damaged by rough handling.

**CAUTION:** **BURN HAZARD. This accessory will be hot during use and will retain heat for some time after.** Always use protective oven gloves or a pot holder when handling the tray during, and immediately after use. Keep children away from the grill during use.

Robert H. Peterson Co. • 14724 East Proctor Avenue • City of Industry, CA 91746



REV 0 - A - 2205271500

L-C2-688